

To Achieve the Best Performance with Your Sound ID 300 Headset:

- Place the phone in a belt holder or maintain a line-of-sight. Holding the phone in your hand reduces the wireless signals.
- Having the mobile phone on the opposite side as your headset or behind you will reduce wireless signals. Keep the mobile phone and headset on the same side, preferably line-of-sight. If you experience intermittent static, reposition the phone to find the best reception.

DO



DON'T

- As you increase the separation between your phone and your headset the wireless signal strength will be reduced and will produce static and/or disconnect. Reduce the distance.
- If you put your phone in a purse or briefcase, keep the purse or briefcase on the same side as the headset.

Personal Sound Update

Sound ID has added a fourth Personal Sound mode that turns the noise reduction off. To turn noise reduction off, hold the Volume/Personal Sound button down for two seconds to cycle through the modes until you hear four beeps. The Personal Sound settings are as follows:

- One beep: Normal listening enhancement.
- Two beeps: Moderate listening enhancement.
- Three beeps: Strong listening enhancement.
- Four beeps: Noise reduction off.